

# Vacuum Cleaner Batteries



Vacuum cleaner batteries from MicroBattery should be your first choice when it comes to high quality, low cost battery upgrade for your robot vacuum cleaner.

Vacuum cleaner batteries are very important parts of every portable cordless vacuum cleaner. If you have a vacuum cleaner with the best characteristics on paper, but your battery pack is failing quickly, you will not be satisfied as a whole.

Go with MicroBattery - our batteries are carefully tested and certified before leaving factory.

PART NO.	DESCRIPTION	DESCRIPTION 2	OEM PART NO.	MODELS
<b>DIRT DEVIL</b>				
MBVC0002	Dirt Devil Evo/Libero Battery	NiMH 7.2V 1500mAh 10.8Wh	0678004	Dirt Devil Evo M678, Dirt Devil Libero M678
MBVC0001	Dirt Devil Libero Battery	NiMH 14.4V 800mAh 11.5Wh	0606004	Dirt Devil Libero M606
<b>ELECTROLUX</b>				
MBVC0003	Electrolux Trilobite Battery	NiMH 18V 3000mAh 54Wh	2192119010	Electrolux Trilobite ZA1, ZA2
<b>iROBOT</b>				
MBVC0005	iRobot Braava Battery	NiMH 7.2V 2000mAh 14.4Wh	4409709, GPRHC202N026	iRobot Braava 380, 380T
MBVC0004	iRobot Braava/Mint Battery	NiMH 7.2V 1500mAh 10.8Wh	4408927, GPRHC152M073	iRobot Braava 320, Mint 4200, 4205
MBVC0006	iRobot Roomba Battery	NiMH 14.4V 3300mAh 47.5Wh	17373	iRobot Roomba 400 Series
MBVC0007	iRobot Roomba Battery	NiMH 14.4V 3300mAh 47.5wh	4419696	iRobot Roomba 500, 600, 700, 800 Series, Discovery 800 Series, Scooba 450
MBVC0024	iRobot Scooba Battery	Li-ion 7.2V 1500mAh 10.8Wh	21003	iRobot Scooba 200, 230
MBVC0008	iRobot Scooba Battery	NiMH 14.4V 3600mAh 51.8Wh	14904	iRobot Scooba 300 Series, 5000 Series, 6050


**DIRT DEVIL**



**ELECTROLUX**



**iROBOT**



PART NO.	DESCRIPTION	DESCRIPTION 2	OEM PART NO.	MODELS
<b>DYSON</b>				
MBVC0018	Dyson DC16 Battery	Li-ion 21.6V 1500mAh 32.4Wh	12097, BP01, 912433-01	Dyson DC16
MBVC0019	Dyson DC30 Battery	Li-ion 14.4V 1500mAh 21.6Wh	917083-02	Dyson DC30
MBVC0020	Dyson DC31 Battery	Li-ion 22.2V 1500mAh 33.3Wh	917083-01, 917083-04	Dyson DC31, DC34, DC35 (before June 2013), DC44 Animal, DC45
MBVC0021	Dyson DC35 Battery	Li-ion 22.2V 1500mAh 33.3Wh	202932-02, 202932-03	Dyson DC35 (after June 2013), DC57
MBVC0022	Dyson DC62 Battery	Li-ion 21.6V 1500mAh 32.4Wh	61034-01, 965874-02	Dyson DC58, DC59, DC61, DC62, DC62 Animal, DC72, DC74 Animal, V6 Series
MBVC0023	Dyson DC62 Battery	Li-ion 21.6V 2500mAh 54Wh	61034-01, 965874-02	Dyson DC58, DC59, DC61, DC62, DC62 Animal, DC72, DC74 Animal, V6 Series
<b>KAERCHER</b>				
MBVC0025	Kaercher RC3000 Battery	Li-ion 6V 2000mAh 12Wh	2.891-029.0	Kaercher Robot Cleaner RC3000
<b>NEATO</b>				
MBVC0009	Neato Botvac Battery	NiMH 12V 2000mAh 24Wh	945-0129	Neato Botvac 70e, 75, 80, 85
MBVC0010	Neato Botvac Battery	NiMH 12V 3000mAh 36Wh	945-0129	Neato Botvac 70e, 75, 80, 85
MBVC0011	Neato XV Battery	NiMH 7.2V 3500mAh 25.2Wh	945-0006, 205-0001, 945-0005, 945-0024, 205-0001	Neato Signature 25, XV Signature, XV Signature Pro, XV-11, XV-12, XV-14, XV-15, XV-21


DYSON



KAERCHER



NEATO



PART NO.	DESCRIPTION	DESCRIPTION 2	OEM PART NO.	MODELS
<b>PHILIPS</b>				
MBVC0012	Philips Easystar Battery	NiMH 14.4V 800mAh 11.5Wh	432200624651	Philips Easystar FC8800, FC8802
<b>SAMBA</b>				
MBVC0016	Samba XR210 Battery	NiMH 14.4V 2000mAh 28.8Wh	0612092014, 35601254, NS3000D03X3, YX-NI-MH-022144, YX-NI-MH-022144	Samba XR210, Samba R Series
MBVC0017	Samba XR210 Battery	NiMH 14.4V 2000mAh 28.8Wh	0612092014, 35601254, NS3000D03X3, YX-NI-MH-022144, YX-NI-MH-022144	Samba XR210, Samba R Series
<b>SAMSUNG</b>				
MBVC0013	Samsung Navibot Battery	NiMH 14.4V 2000mAh 28.8Wh	DJ96-00136B	Samsung Navibot VCR8875
MBVC0014	Samsung Navibot Battery	NiMH 14.4V 3000mAh 43.2Wh	DJ96-00136B	Samsung Navibot VCR8875
MBVC0015	Samsung Navibot Battery	NiMH 14.4V 2600mAh 37.4Wh	DJ96-00113A, DJ96-0083C, SAM14.49B	Samsung Navibot VC-RE70V, VC-RE72V

PHILIPS



SAMBA



SAMSUNG

